


S4554GNS-LP



Features

- 88 Channel GLONASS+GPS L1 C/A Code
- Perform 10 million time-frequency hypothesis testing per second
- Open sky hot start 1 sec
- Open sky cold start 29 sec
- Cold start sensitivity -145dBm
- Navigation sensitivity -159dBm
- Accuracy 2.5m CEP
- 400mW acquisition
- 250mW tracking
- Operating temperature -40 ~ +85°C
- RoHS compliant

Applications

- Automotive Navigation
- Vehicle Tracking
- Marine Navigation
- Timing reference

S4554GNS-LP

High-Performance 88 Channel GLONASS + GPS Receiver

The S4554GNS-LP offers GPS+GLONASS positioning to provide increased satellite availability for positioning in challenging environments at a very cost-effective price. It offers 24 tracking channels of L1 GPS and GLONASS code and carrier phase tracking for increased positioning accuracy and availability.


The S4554GNS-LP features 88 channel GPS receiver with fast time to first fix and improved -145dBm cold start sensitivity. The superior cold start sensitivity allows it to acquire, track, and get position fix autonomously in difficult weak signal environment. The receiver's -159dBm navigation sensitivity allows continuous position coverage in nearly all application environments. The high performance search engine is capable of testing 10,000,000 time-frequency hypotheses per second, offering industry-leading signal acquisition and TTFF speed.

The receiver is suitable for in vehicle car navigation system that requires high performance continuous navigation and low cost.

TECHNICAL SPECIFICATIONS


| | |
|-----------------------|---|
| Receiver Type | L1 C/A code, 88-channel |
| Modes | GLONASS, GPS, GLONASS + GPS |
| Accuracy | Position 2.5m CEP Velocity 0.1m/sec Time 60ns |
| Startup Time | 1 second hot start under open sky < 29 second warm start under open sky (average) 29 second cold start under open sky (average) |
| Reacquisition | 1s |
| Sensitivity | -145dBm cold start -159dBm navigation |
| Update Rate | 1Hz |
| Operational Limits | Altitude < 18,000m or velocity < 515m/s |
| Serial Interface | 3.3V LVTTTL level |
| Protocol | NMEA-0183 V3.01 GPGGA, GNGLL, GNGNS, GPGSA, GLGSA, GNGSA GPGSV, GLGSV, GNVTG, GNRMC 9600 baud, 8, N, 1 |
| Datum | Default WGS-84 User definable |
| Input Voltage | 3.3V DC +/-5% |
| Power Consumption | 400mW acquisition 250mW tracking |
| Dimension | 54mm L x 45mm W |
| Weight: | 12g |
| Interface Connector | 20 pin male header, 2.0mm pitch |
| Operating Temperature | -40°C ~ +85°C |
| Storage Temperature | -55 ~ +100°C |
| Humidity | 5% ~ 95% |

BLOCK DIAGRAM



Functional Block Diagram

INTERFACE




20-Pin Header 2.0mm Pitch

PINOUT DESCRIPTION

| Pin No. | Name | Description |
|---------|--------|---|
| 1 | VIN33 | +3.3V +/- 5% DC power input |
| 2 | GND | System ground |
| 3 | NC | No connection |
| 4 | NC | No connection |
| 5 | NC | No connection |
| 6 | NC | No connection |
| 7 | ENA | Enable control. 1:ON, 0:OFF |
| 8 | NC | No connection |
| 9 | NC | No connection |
| 10 | NC | No connection |
| 11 | RESETN | External active-low reset input. $V_{IH} > 2.3V$, $V_{IL} < 0.8V$ Can be left NC if not used. |
| 12 | NC | No connection |
| 13 | FTXD0 | UART serial data output, 3V LVTTTL. One full-duplex asynchronous serial UART port is implemented. This UART output is normally used for sending position, time and velocity information from the receiver in NMEA-0183 format. When idle, this pin output HIGH. $2.8V < V_{OH} < 3.3V$, $0V < V_{OL} < 0.5V$ |
| 14 | FRXD0 | UART serial data input, 3V LVTTTL. One full-duplex asynchronous serial UART port is implemented. This UART input is normally for sending commands or information to the receiver in SkyTraq binary protocol. In the idle condition, this pin should be driven HIGH. If the driving circuitry is powered independently of S4554GNS-LP, ensure that this pin is not driven to HIGH when primary power to S4554GNS-LP is removed, or a 10K-ohm series resistor can be added to minimize leakage current from application to the powered off module. $V_{IH} > 2.3V$, $V_{IL} < 0.8V$ |

| | | |
|----|-------|--|
| 15 | P1PPS | One-pulse-per-second (1PPS) time mark output, 3V LVTTL. The rising edge synchronized to UTC second when getting 3D position fix. The pulse duration is about 4msec at rate of 1 Hz. $2.8V < V_{OH} < 3.3V$, $0V < V_{OL} < 0.5V$ |
| 16 | VBAT | Backup supply voltage for internal RTC and backup SRAM, 1.5V ~ 6V. VBAT must be applied whenever VIN33 is applied. This pin should be powered continuously to minimize the startup time. If VIN33 and VBAT are both removed, the receiver will be in factory default mode upon power up, all user configuration set is lost. For applications the does not care cold starting every time, this pin can be connect to VIN33. |
| 17 | FTXD1 | UART serial data output, 3V LVTTL. One full-duplex asynchronous serial UART port is implemented. When idle, this pin output HIGH. $2.8V < V_{OH} < 3.3V$, $0V < V_{OL} < 0.5V$ |
| 18 | FRXD1 | UART serial data input, 3V LVTTL. One full-duplex asynchronous serial UART port is implemented. In the idle condition, this pin should be driven HIGH. If the driving circuitry is powered independently of S4554GNS-LP, ensure that this pin is not driven to HIGH when primary power to S4554GNS-LP is removed, or a 10K-ohm series resistor can be added to minimize leakage current from application to the powered off module. $V_{IH} > 2.3V$, $V_{IL} < 0.8V$ |
| 19 | VIN33 | +3.3V +/- 5% DC power input |
| 20 | GND | System ground |

MECHANICAL DIMENSION



ELECTRICAL SPECIFICATIONS

ABSOLUTE MAXIMUM RATINGS

| Parameter | Minimum | Maximum | Condition |
|-------------------------------|---------|-----------|-----------|
| Supply Voltage (VIN33) | -0.5 | 3.6 | Volt |
| Backup Battery Voltage (VBAT) | -0.5 | 6 | Volt |
| Input Pin Voltage | -0.5 | VIN33+0.5 | Volt |
| Input Power at RFIN | | +5 | dBm |
| Storage Temperature | -55 | +100 | degC |

OPERATING CONDITIONS

| Parameter | Min | Typ | Max | Unit |
|--|-----|-----|-----|------|
| Supply Voltage (VIN33) | 3 | 3.3 | 3.6 | Volt |
| Acquisition Current (exclude active antenna current) | | 120 | | mA |
| Tracking Current (exclude active antenna current) | | 76 | | mA |
| Backup Voltage (VBAT) | 1.5 | | 6 | Volt |
| Backup Current (VIN33 voltage applied) | | | 1.5 | mA |
| Backup Current (VIN33 voltage off) | | | 10 | uA |
| Output Low Voltage | | | 0.4 | Volt |
| Output HIGH Voltage | 2.4 | | | Volt |
| Input LOW Voltage | | | 0.8 | Volt |
| Input HIGH Voltage | 2 | | | Volt |
| Input LOW Current | -10 | | 10 | uA |
| Input HIGH Current | -10 | | 10 | uA |
| RF Input Impedance (RFIN) | | 50 | | Ohm |

POWER SUPPLY REQUIREMENT

S4554GNS-LP requires a stable power supply, avoid ripple on VIN33 pin (<50mVpp). Power supply noise can affect the receiver's sensitivity. Bypass capacitors should be placed close to the module VIN33 pin, with values adjusted depending on the amount and type of noise present on the supply line.

BACKUP SUPPLY

The purpose of backup supply voltage pin (VBAT) is to keep the SRAM memory and the RTC powered when the module is powered down. This enables the module to have a faster time-to-first-fix when the module is powered on again. The backup current drain is less than 10 μ A. In normal powered on state, the internal processor access the SRAM and current drain is higher in active mode

ANTENNA CONSIDERATION

3.3V DC bias voltage is provided on the SMA RF input connector; short circuit current limit is 70mA. Active antenna with gain up to 30dB and noise figure less than 2dB can be used.

NMEA Output Description

The NMEA message output by the SkyTraq GPS/GLONASS receiver has the following sentence structure:

`$aacc,c--c*hh<CR><LF>`

The detail of the sentence structure is explained in Table 1.

Table 1: The NMEA sentence structure

| character | HEX | Description |
|-----------|------|---|
| "\$" | 24 | start of the sentence/message |
| aacc | | address field. The first 2 characters "aa" identify the talker/transmitting terminal (talker identifier). The last 3 characters "ccc" identify the NMEA message type. |
| "," | 2C | the field delimiter |
| c--c | | the data sentence block |
| "*" | 2A | the checksum delimiter |
| hh | | checksum field |
| <CR><LF> | 0D0A | end of sentence/message (carriage return, line feed) |

There are three types of talker identifiers (see section six, NMEA 0183 standard) for the NMEA output from SkyTraq GPS/GLONASS receiver. The three types of talker identifiers are GP, GL and GN and they stand for the data related to the GPS, GLONASS and the combined system, respectively.

In the default setting, SkyTraq GPS/GLONASS receiver calculates the PVT solution using the combination of GPS and GLONASS satellites. In some circumstances, however, only the GPS or the GLONASS satellite signals are available for the GPS/GLONASS receiver. The solution may be then performed based on either single or combined satellite systems according to the actual satellite constellation.

Currently, the messages GGA/GNS/GSA/GSV/RMC/VTG are supported in the GPS/GLONASS receiver. The NMEA messages and the corresponding information content are listed in Table 2. The matching talker identifiers for each NMEA message are also listed in Table 2. The combination of talker identifiers and the NMEA messages is used for reporting satellite and navigation information under different satellite constellations. The detail is explained in the following.

Table 2: Supported NMEA Message List

| NMEA Message | Information Content | Possible Talker Identifiers |
|--------------|---|-----------------------------|
| GGA | Time, position, and fix related data for the SkyTraq receiver. | GP |
| GNS | Time, position and fix related data of GPS, GLONASS or combined systems. | GN |
| GSA | Receiver operating mode, satellites used in the PVT solution, and DOP values. | GP, GL, GN |
| GSV | Number of satellites in view, satellite ID, elevation, azimuth and SNR value. | GP, GL |
| VTG | Course and speed relative to the ground. | GN |
| RMC | Time, date, position, course and speed data. | GN |

GGA - Global Positioning System Fix Data

Time, position and fix related data for a GPS receiver.

Format:

\$--GGA,hhmmss.ss,lll.lll,a,yyyyy.yyy,a,x,uu,v.v,w.w,M,x.x,M,,zzzz*hh<CR><LF>

| Field | Name | Description |
|-----------|-----------------------|---|
| hhmmss.ss | UTC Time | UTC of position in hhmmss.sss format, (000000.000 ~ 235959.999) |
| lll.lll | Latitude | Latitude in ddmm.mmmm format Leading zeros transmitted |
| a | N/S Indicator | Latitude hemisphere indicator, 'N' = North, 'S' = South |
| yyyyy.yyy | Longitude | Longitude in dddmm.mmmm format Leading zeros transmitted |
| a | E/W Indicator | Longitude hemisphere indicator, 'E' = East, 'W' = West |
| x | GPS quality indicator | GPS quality indicator 0: position fix unavailable 1: valid position fix, SPS mode 2: valid position fix, differential GPS mode 3: GPS PPS Mode, fix valid 4: Real Time Kinematic. System used in RTK mode with fixed integers 5: Float RTK. Satellite system used in RTK mode. Floating integers 6: Estimated (dead reckoning) Mode 7: Manual Input Mode 8: Simulator Mode |
| uu | Satellites Used | Number of satellites in use, (00 ~ 24) |
| v.v | HDOP | Horizontal dilution of precision, (00.0 ~ 99.9) |
| w.w | Altitude | mean sea level altitude (-9999.9 ~ 17999.9) in meter |
| x.x | Geoidal Separation | In meter |
| zzzz | DGPS Station ID | Differential reference station ID, 0000 ~ 1023 NULL when DGPS not used |
| hh | Checksum | |

When the GGA message is turned on, the talker identifier is always set to GP, regardless of whether the position solution is based on GPS, GLONASS satellites or the combination.

GNS message:

Format:

\$--GNS,hhmmss.ss,lll.lll,a,yyyyy.yyy,a,cc,uu,v.v,w.w,x.x,,*hh<CR><LF>

| Field | Name | Description |
|--------------|--------------------|---|
| hhmmss.ss | UTC Time | UTC of position in hhmmss.sss format, (000000.000 ~ 235959.999) |
| lll.lll, | Latitude | Latitude in ddmm.mmmm format Leading zeros transmitted |
| a | N/S Indicator | Latitude hemisphere indicator, 'N' = North, 'S' = South |
| yyyyy.yyy | Longitude | Longitude in dddmm.mmmm format Leading zeros transmitted |
| a | E/W Indicator | Longitude hemisphere indicator, 'E' = East, 'W' = West |
| cc | Mode Indicator | Two characters with the first indicate the use of GPS satellites, and the second indicate the use of GLONASS satellites. N: No fix A: Autonomous, non-differential mode D: Differential mode P: Precise, no SA, higher resolution (P-code) used R: Real Time Kinematic. System used in RTK mode with fixed integers F: Float RTK. Satellite system used in RTK mode. Floating integers E: Estimated (dead reckoning) Mode M: Manual Input Mode S: Simulator Mode |
| uu | Satellites Used | Number of satellites in use, (00 ~ 24) |
| v.v | HDOP | Horizontal dilution of precision, (00.0 ~ 99.9) |
| w.w | Altitude | Mean sea level altitude (-9999.9 ~ 17999.9) in meter |
| x.x | Geoidal Separation | In meter |
| hh | Checksum | |

By default, the receiver uses the GNS message to report the position data. For the GNS message, currently supported talker identifier is GN. The mode indicator is used to denote which GNSS type is used in the navigation solution. There are two characters in the mode indicator. The first character is for GPS system while the second character is for GLONASS system. For example, when only GPS satellites are used for (non-differential) navigation solution, the mode indicator will be "AN". When only GLONASS satellites are used for (non-differential) navigation solution, the mode indicator will be "NA". Only when both GPS and GLONASS satellites are used in the (non-differential) navigation solution, the mode indicator will become "AA".

GSA – GNSS DOP and Active Satellites

GPS receiver operating mode, satellites used in the navigation solution reported by the GGA or GNS sentence and DOP values.

Format:

\$--GSA,a,x,xx,xx,xx,xx,xx,xx,xx,xx,xx,xx,u.u,v.v,z.z*hh<CR><LF>

| Field | Name | Description |
|-------|---------------------|--|
| a | Mode | Mode 'M' = Manual, forced to operate in 2D or 3D mode 'A' = Automatic, allowed to automatically switch 2D/3D |
| x | Mode | Fix type 1 = Fix not available 2 = 2D 3 = 3D |
| xx | Satellite used 1~12 | Satellite ID number, 01 to 32, of satellite used in solution, up to 12 transmitted |
| u.u | PDOP | Position dilution of precision (00.0 to 99.9) |
| v.v | HDOP | Horizontal dilution of precision (00.0 to 99.9) |
| z.z | VDOP | Vertical dilution of precision (00.0 to 99.9) |
| hh | Checksum | |

When only GPS satellites are used in position solution, the talker identifier is GP. When only GLONASS satellites are used in position solution, the talker identifier is GL. When both GPS and GLONASS satellite are used together in the position solution, the talker identifier will be GN. In the third case, the receiver creates two GSA sentences for every epoch. The first GNGSA sentence is used for GPS satellites while the second one is for the GLONASS satellites. In the GSA message, the satellite ID number of the GLONASS satellite is 64+satellite slot number.

GSV – GNSS Satellites in View

Number of satellites (SV) in view, satellite ID numbers, elevation, azimuth, and SNR value. Four satellites maximum per transmission.

Format:

\$--GSV,x,u,xx,uu,vv,zzz,ss,uu,vv,zzz,ss,...,uu,vv,zzz,ss*hh<CR><LF>

| Field | Name | Description |
|-------|--------------------|--|
| x | Number of message | Total number of GSV messages to be transmitted (1-3) |
| u | Sequence number | Sequence number of current GSV message |
| xx | Satellites in view | Total number of satellites in view (00 ~ 12) |
| uu | Satellite ID | Satellite ID number, GPS: 01 ~ 32, SBAS: 33 ~ 64 (33 = PRN120) |
| vv | Elevation | Satellite elevation in degrees, (00 ~ 90) |
| zzz | Azimuth | Satellite azimuth angle in degrees, (000 ~ 359) |
| ss | SNR | C/No in dB (00 ~ 99) Null when not tracking |
| hh | Checksum | |

The GSV sentence has two possible talker identifiers: GP and GL. The GPS/GLONASS receiver outputs separate GSV sentences to report satellite information for GPS and GLONASS systems. The GPGSV is for GPS satellites while GLGSV is for GLONASS satellites. The GN identifier is not supported in GSV message. In the GSV message, the satellite ID number of the GLONASS satellite is 64+satellite slot number.

RMC – Recommended Minimum Specific GNSS Data

Time, date, position, course and speed data provided by a GNSS navigation receiver.

Format:

\$--RMC,hhmmss.sss,x,lll.lla,yyyy.yyy,a,x.x,u.u,xxxxx,,v*hh<CR><LF>

| Field | Name | Description |
|------------|--------------------|--|
| hhmmss.sss | UTC time | UTC time in hhmmss.sss format (000000.000 ~ 235959.999) |
| x | Status | Status 'V' = Navigation receiver warning 'A' = Data Valid |
| lll.lla | Latitude | Latitude in dddmm.mmmm format Leading zeros transmitted |
| a | N/S indicator | Latitude hemisphere indicator 'N' = North 'S' = South |
| yyyyy.yyy | Longitude | Longitude in dddmm.mmmm format Leading zeros transmitted |
| a | E/W Indicator | Longitude hemisphere indicator 'E' = East 'W' = West |
| x.x | Speed over ground | Speed over ground in knots (000.0 ~ 999.9) |
| u.u | Course over ground | Course over ground in degrees (000.0 ~ 359.9) |
| xxxxxx | UTC Date | UTC date of position fix, ddmmyy format |
| v | Mode indicator | Mode indicator 'N' = Data not valid 'A' = Autonomous mode 'D' = Differential mode 'E' = Estimated (dead reckoning) mode 'M' = Manual input mode 'S' = Simulator mode |
| hh | checksum | |

The GPS/GLONASS receiver uses talker identifier GN for the RMC messages to indicate that it is operating in the combined GPS/GLONASS mode.

VTG – Course Over Ground and Ground Speed

The Actual course and speed relative to the ground.

Format:

\$--VTG,x.x,T,,M,v.v,N,u.u,K,m*hh<CR><LF>

| Field | Name | Description |
|--------------|-------------|---|
| x.x | Course | True course over ground in degrees (000.0 ~ 359.9) |
| v.v | Speed | Speed over ground in knots (000.0 ~ 999.9) |
| u.u | Speed | Speed over ground in kilometers per hour (0000.0 ~ 1800.0) |
| m | Mode | Mode indicator 'N' = not valid 'A' = Autonomous mode 'D' = Differential mode 'E' = Estimated (dead reckoning) mode 'M' = Manual input mode 'S' = Simulator mode |
| hh | Checksum | |

The GPS/GLONASS receiver uses talker identifier GN for the VTG messages to indicate that it is operating in the combined GPS/GLONASS mode.

In the following examples, we illustrate the use of GNS/GSA/GSV messages for different satellite constellations.

Examples:

Case 1: Only GPS satellites are available for the navigation solution.

```
$GNGNS,083613.333,2447.0963,N,12100.5393,E,AN,07,1.6,138.8,19.6,,0000*60
$GPGSA,A,3,03,19,24,08,20,32,28,,,,,,,,,2.7,1.0,2.5*23
$GPGSV,3,1,12,11,82,240,20,07,62,241,21,08,45,304,28,19,35,038,31*72
$GLGSV,1,1,01,75,67,268,25,,,,,,,,,,,,,*B3 (this sentence is present if GLONASS satellites are tracked by the receiver)
:
:
:
```

Case 2: Only GLONASS satellites are available for the navigation solution.

```
$GNGNS,083613.333,2447.0963,N,12100.5393,E,NA,04,1.6,138.8,19.6,,0000*60
$GLGSA,A,3,71,72,87,86,,,,,,,,,2.7,1.0,2.5*25
$GPGSV,1,1,1,11,82,240,20,,,,,,,,,,,,,*2A (this sentence is present if GPS satellites are tracked by the receiver)
$GLGSV,2,1,05,71,73,268,38,72,45,279,37,87,42,000,33,86,36,287,35*65
$GLGSV,2,2,05,74,39,268,28,,,,,,,,,,,,,*34
:
:
:
```

Case 3: Both GPS and GLONASS satellites are available for the navigation solution.

```
$GNGNS,083613.333,2447.0963,N,12100.5393,E,AA,08,1.6,138.8,19.6,,0000*60
$GNGSA,A,3,03,19,24,08,20,32,,,,,,,,,2.7,1.0,2.5*23
$GNGSA,A,3,87,72,,,,,,,,,2.7,1.0,2.5*25
$GPGSV,3,1,7,03,82,240,41,19,62,241,40,24,45,304,39,08,35,038,38*72
$GPGSV,3,2,7,20,35,143,38,32,51,221,37,02,04,135,27,,,,,*72
$GLGSV,1,1,03,87,73,268,38,72,42,041,36,65,36,287,,,,,*78
:
:
```

Summary

The supported NMEA messages of SkyTraq GPS/GLONASS receiver and the meaning are summarized in the following list.

| NMEA message with the talker identifier | Meaning |
|---|---|
| GPGGA | The fix data from GPS/GLONASS receiver. |
| GNGNS | The fix data from GPS/GLONASS receiver. |
| GPGSA | The information of the satellites used in GPS-only navigation solution |
| GLGSA | The information of the satellites used in GLONASS-only navigation solution |
| GNGSA | Navigation solution based on combined satellite systems is provided. Two sentences are output for every navigation epoch. The first and the second sentence provide information about GPS and GLONASS satellites which are used in the navigation solution, respectively. |
| GPGSV | The information of the GPS satellites in view of the receiver. |
| GLGSV | The information of the GLONASS satellites in view of the receiver. |
| GNRMC | Time, date, position, course and speed information for GPS/GLONASS receiver. |
| GNTVG | Course and speed information relative to the ground for GPS/GLONASS receiver. |

ORDERING INFORMATION

| Model Name | Description |
|-------------|-----------------------------|
| S4554GNS-LP | GLONASS/GPS Receiver Module |

The information provided is believed to be accurate and reliable. These materials are provided to customers and may be used for informational purposes only. No responsibility is assumed for errors or omissions in these materials, or for its use. Changes to specification can occur at any time without notice.

These materials are provided "as is" without warranty of any kind, either expressed or implied, relating to sale and/or use including liability or warranties relating to fitness for a particular purpose, consequential or incidental damages, merchantability, or infringement of any patent, copyright or other intellectual property right. No warrant on the accuracy or completeness of the information, text, graphics or other items contained within these materials. No liability assumed for any special, indirect, incidental, or consequential damages, including without limitation, lost revenues or lost profits, which may result from the use of these materials.

The product is not intended for use in medical, life-support devices, or applications involving potential risk of death, personal injury, or severe property damage in case of failure of the product.
